

Nokia 770 Internet Tablet

– Instructions for software update

1. INTRODUCTION

This document describes how to install the Nokia 770 software update wizard on your computer, and how to use the wizard to update the software on your Nokia 770 Internet Tablet.

2. REQUIREMENTS FOR YOUR COMPUTER

The Nokia 770 software update wizard is compatible with the following computer operating systems:

- Microsoft Windows 2000 with Service Pack 3 or newer
- Microsoft Windows XP with Service Pack 1 or newer

Before you install the Nokia 770 software update wizard, check the version number of the operating system on your computer for compatibility.


Windows 2000: Open the *Start* menu, and select *Settings > Control Panel > System*.
Windows XP: Open the *Start* menu, and select *Control Panel > System*.

For more instructions related to the use of the computer, refer to its user guide.

3. INSTALL THE NOKIA 770 SOFTWARE UPDATE WIZARD

To be able to update the software on your Nokia 770 Internet Tablet, you must first install the Nokia 770 software update wizard on your computer.

Download [Nokia_770_software_update_wizard.exe](#) to your computer. Open the file, and follow the instructions on the screen to complete the installation.





Note: The Nokia 770 software update wizard needs a Nokia connectivity cable driver. The driver is installed automatically if needed.


4. UPDATE THE SOFTWARE ON YOUR NOKIA 770 INTERNET TABLET



Before you can begin the software update, you must have the following available:

- Nokia connectivity cable DKE-2 (USB) for connecting the device to your computer.
- Fully charged battery for your device.
- The latest software file for the device. See www.nokia.com/770/support.

 **Important:** Make sure the battery of your device is fully charged. If the device loses power, or any other disruption takes place during the update, you need to rerun the wizard.

 **Important:** Back up data saved on your device. Otherwise you will lose all data while updating the software. For further instructions, see the Nokia 770 user guide.

 **Important:** Connecting the charger will prevent you from updating the software.


 **Tip:** To check the version number of the current software on your device, tap  on the task navigator, and select *Control panel* > *Device* > *About product*.


To access the Nokia 770 software update wizard on your computer, do the following:

Windows 2000: Open the *Start* menu and select *Programs* > *Nokia 770 software update wizard* > *Nokia 770 software update wizard*.

Windows XP: Open the *Start* menu and select *All Programs* > *Nokia 770 software update wizard* > *Nokia 770 software update wizard*.

Follow the instructions on the screen to update the software on your device.



 **Note:** When you connect your device to the computer for the first time, a dialog is displayed on the screen of the computer stating that a new device has been found.

After the update is complete, disconnect the USB cable from the device. The device reboots automatically, and the changes take effect.